

No.	ADA NAME	Name
1	GD5EA01	Screw M5x14
2	GD5EA02	Screw M5x20
3	GD5EA03	lfiguration
4	GD5EA04	Screw M5x30
5	GD5EA05	Screw M5x25
6	GD5EA06	Side cover
7	GD5EA07	Nut 5x10
8	GD5EA08	Screw ø9.5xM8x24
9	GD5EA09	Gasket ø10
10	GD5EA10	Clutch
11	GD5EA11	M8 Screw
12	GD5EA12	Fly wheel
13	GD5EA13	Screw M5x14
14	GD5EA14	Half part 3x5x13
15	GD5EA15	Screw M5x35
16	GD5EA16	Oil seal 15x30x7
17	GD5EA17	Left crank case
18	GD5EA18	Bearing 6202
19	GD5EA19	Piston clip ø9.5x0.8
20	GD5EA20	Piston nut
21	GD5EA21	Piston bearing 10x14x16
22	GD5EA22	Screw M6x50
23	GD5EA23	Screw M5x14
24	GD5EA24	Muffler
25	GD5EA25	Muffler gasket
26	GD5EA26	Cylinder clapboard
27	GD5EA27	Fuel tank holder
28	GD5EA28	Entrence gasket
29	GD5EA29	Air entrence
30	GD5EA30	Carburetor gasket
31	GD5EA31	Carburetor
32	GD5EA32	Air filter button
33	GD5EA33	Screw M5x50
34	GD5EA34	Air filter plate
35	GD5EA35	Air filter sponge
36	GD5EA36	Air filter cover
37	GD5EA37	Screw M5x16
38	GD5EA38	Screw M5x16
39	GD5EA39	Cylinder cover
40	GD5EA40	Spark plug
41	GD5EA41	Cylinder
42	GD5EA42	Cylinder gasket
43	GD5EA43	Piston ring (2pcs)
44	GD5EA44	Piston
45	GD5EA45	Crankshaft
46	GD5EA46	crank case gasket
47	GD5EA47	Right crank case
48	GD5EA48	Oil seal 12x22x7
49	GD5EA49	Fuel tank
50	GD5EA50	Gasket 8x16x1.6
51	GD5EA51	Starter plate
52	GD5EA52	Fuel tank plate AVS
53	GD5EA53	Fuel tank plate
54	GD5EA54	Starter easy start
55	GD5EA55	Starter handle

Assy s-parts

56	GD5EA56	Air filter assy (32.34.35.36)
57	GD5EA57	Clutch spring
58	GD5EA58	Fuel tank cap assy
59	GD5EA59	Fuel tube assy (Tube+rubber+fuel filter)

